


ANSI Pump Reference Guide

Sizes Available

- ☐ 1x1.5-6
- ☐ 1.5x3-6
- ☐ 2x3-6
- ☐ 1x1.5-8
- ☐ 1.5x3-8

Part #	Name
100	Casing (Volute)
101	Impeller
112	Outboard (Thrust) Bearing
113	Oil Fill Plug
119	Inboard Bearing Cover
122	Solid Shaft and Hook Shaft
123	Deflector
126	Shaft Sleeve
134	Bearing Housing
136	Bearing Locknut
168	Inboard Bearing
184	Stuffing Box (Back Plate)
228	Frame
241	Frame Foot
250	Gland
251A	Oiler
251B	Oiler Nipple
319	View Gauge
332A	Outboard Labyrinth Oil Seal
333B	Outboard Oil Seal
333A	Inboard Labyrinth Oil Seal
333B	Inboard Oil Seal
351	Casing Gasket
358	Casing Drain Plug
361	Bearing Housing Retaining Ring
370	Cap Screw, Adapter to Casing
382	Bearing Lockwasher
408	Oil Drain Plug
412	Impeller Gasket
418	Jacking Bolts
496	Bearing Housing O-Ring
Kits	Repair Kit
	Maintenance Kit



Compare with
Goulds Model 3196 STX™

ANSI Pump Reference Guide


Sizes Available

- ☐ 3x4-7
- ☐ 2x3-8
- ☐ 3x4-8
- ☐ 3x4-8G
- ☐ 1x2-10
- ☐ 1.5x3-10
- ☐ 2x3-10
- ☐ 3x4-10
- ☐ 3x4-10H
- ☐ 4x6-10
- ☐ 4x6-10G
- ☐ 4x6-10H
- ☐ 1.5x3-13
- ☐ 2x3-13
- ☐ 3x4-13
- ☐ 4x6-13

Part

Name

100	Casing (Volute)
101	Impeller
108	Frame Adapter
112	Outboard (Thrust) Bearing
113	Oil Fill Plug
122	Solid Shaft and Hook Shaft
123	Deflector
126	Shaft Sleeve
134	Bearing Housing
136	Bearing Locknut
168	Inboard Bearing
184	Stuffing Box (Back Plate)
228	Frame
241	Frame Foot
250	Gland
251A	Oiler
251B	Oiler Nipple
319	View Gauge
332A	Outboard Labyrinth Oil Seal
333B	Outboard Oil Seal
333A	Inboard Labyrinth Oil Seal
333B	Inboard Oil Seal
351	Casing Gasket
358	Casing Drain Plug
360F	Frame to Adapter Gasket
361	Bearing Housing Retaining Ring
370	Cap Screw, Adapter to Casing
382	Bearing Lockwasher
408	Oil Drain Plug
412	Impeller Gasket
418	Jacking Bolts
496	Bearing Housing O-Ring
Kits	Repair Kit
	Maintenance Kit



Compare with
Goulds Model 3196 MTX™




Valley Equipment Company Inc.

ANSI Pump Reference Guide

Sizes Available

- ☐ 6x8-13
- ☐ 8x10-13
- ☐ 6x8-15
- ☐ 8x10-15
- ☐ 8x10-15G
- ☐ 8x10-16H
- ☐ 4x6-17
- ☐ 6x8-17
- ☐ 8x10-17

Part #	Name
100	Casing (Volute)
101	Impeller
108	Frame Adapter
109	Inboard Bearing Cover
112	Outboard (Thrust) Bearing
113	Oil Fill Plug
122	Solid Shaft and Hook Shaft
123	Deflector
126	Shaft Sleeve
134	Bearing Housing
136	Bearing Locknut
168	Inboard Bearing
184	Stuffing Box (Back Plate)
228	Frame
241	Frame Foot
250	Gland
251A	Oiler
251B	Oiler Nipple
319	View Gauge
332A	Outboard Labyrinth Oil Seal
333B	Outboard Oil Seal
333A	Inboard Labyrinth Oil Seal
333B	Inboard Oil Seal
351	Casing Gasket
358	Casing Drain Plug
360C	Gasket, Bearing End Cover
360F	Frame to Adapter Gasket
370	Cap Screw, Adapter to Casing
382	Bearing Lockwasher
408	Oil Drain Plug
412	Impeller Gasket
418	Jacking Bolts
496	Bearing Housing O-Ring
	Repair Kit



Compare with
Goulds Model 3196 XLTX™



Valley Equipment Company Inc.